

PVC DRAIN FLANGE COUPLING

SKU: 399922
Code: SH399922

FEATURES

Material: PVC



ASME A112.18.2/CSA B125.2, Massachusetts Accepted, LISTED ID: SH439001*





ADDITIONAL FEATURES

- Used to connect a flexible, rubber membrane between flooring and tile shower floor.
- Connects 2-1/8" shower drain to waste pipe. Fits over 2-1/8" and inside 3" pipe.
- Includes rubber gasket.
- Made for use with Carmen (928028 & 927531), Cohen (927530 & 928029), Effendi (926148 & 928027), Loup (926146), Ortiz (928030), Siewart (926145), Thornton (928026), Reid (917170), or Werner (926147) Shower Drain, sold separately.

REVISED 2/13/2025

PVC DRAIN FLANGE COUPLING

SKU: 399922
Code: SH399922



REVISED 2/13/2025