



4" CENTERSET FAUCET

INSTALLATION INSTRUCTIONS

Before installing, read entire 4" Centerset Faucet Installation Instructions. Observe all local building and safety codes.

For the following installation instructions for your new 4" Centerset Faucet it is assumed that any old fixtures have been removed and any repairs or modifications to the water supply have been completed.

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1-866-855-2284. If you need assistance or have questions while installing your 4" Centerset Faucet, contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures. Signature Hardware accepts no liability for any damage to the floor, walls, plumbing or for personal injury during installation.

TOOLS AND MATERIALS:

Adjustable wrench
Damp Cloth
Basin Wrench

Silicone Sealant
Drill

Plumbers tape
Hex wrench

INSTALLATION

1. Secure the plastic deck plate to the underside of the faucet base. It should fit inside the faucet base so that it is hidden when your faucet is installed.
2. Apply a bead of silicone sealant to the underside of the deck plate. Run the silicone around the footprint of the faucet.
3. Assemble the faucet and insert into the mounting holes. Align the faucet so that it is parallel to the back of the sink and press firmly into place.
4. Thread a basin nut on each faucet tail-piece. Hand tighten, alternating from on to the other to bring the faucet down evenly over the gasket.
5. Check to make sure that your faucet is properly aligned. From beneath the sink, tighten the mounting hardware with your basin wrench.
6. Wipe away any excess sealant around the base of the faucet using your damp cloth.
7. Hand tighten to attach the main water supply to each faucet tail-piece. Give a ¼ turn with pliers or wrench, but don't over tighten.
8. To install the new pop-up drain, apply a bead of silicone sealant to the underside of the drain flange and place in the mounting hole. If there is no pop-up drain, continue to step 13.
9. Thread the lock nut onto the drain pipe and tighten with your adjustable wrench.
10. Wipe away any excess sealant around the drain using your damp cloth.



11. Push the pop-up rod down through the faucet body. Attach the pop-up rod to the pivot rod with the extension rod. Adjust the rods so that the drain stopper opens and closes properly.
12. Attach the P trap to the drain pipe and wall drain fitting and tighten the lock nuts.
13. When your faucet installation is complete, turn on the water supply. Check to make sure that all connections are tight (no water should be leaking) and that the hot and cold supplies are working correctly. Turn the water on and allow the water to flow through the spout for approximately 60 seconds.