PAGOSA

ROMAN WATERFALL TUB FAUCET AND HANDSHOWER

SKU: 406713

BEFORE YOU BEGIN

We recommend consulting a professional if you are unfamiliar with installing plumbing fixtures. Signature Hardware accepts no liability for any damage to the faucet, plumbing, bathtub or for personal injury during installation.

Observe all local plumbing and building codes.

Unpack and inspect the product for shipping damage. If any damage is found, contact our Customer Relations team at 1-866-855-2284.

GETTING STARTED

• Ensure that you have gathered all the required materials that are needed for the installation.

TOOLS AND MATERIALS:





Basin Wrench

Adjustable Wrench

For Warranty information, please visit: signaturehardware.com/services/warranty

REVISED 03/27/2020 CODES: 518665

PAGOSA

ROMAN WATERFALL TUB FAUCET AND HANDSHOWER

SKU: 406713

INSTALLATION

- 1. If your faucet comes with the brass T attached to the faucet body, unthread and remove the T and associated hardware.
- 2. Thread the mounting washer and rubber sealing gasket on the faucet body and thread the faucet body through the center mounting hole.
- 3. Thread the mounting hardware and brass T onto the body and hand-tighten to secure.
- 4. Check to make sure the faucet is properly aligned and adjust as needed. When the faucet is in the proper position, finish tightening mounting hardware with your adjustable wrench.
- 5. Disassemble the handle bodies. You may need to remove set screws located in the side of the handles with provided allen wrench.
- 6. Insert the handle bodies up through the mounting holes. Secure the handle assemblies to the handle bodies. Make sure that the rubber sealing gasket is between the handle and the mounting surface to ensure a water tight seal.
- 7. With both handles in the OFF position, tighten the set screw on the top or side of the handle with the provided allen wrench.

- 8. Attach the hot and cold flexible water feed tubes to the handle bodies and brass T. (Hot water is always on the left and cold water is always on the right). Curve tubes as necessary to ensure there are no kinks or knots.
- 9. Connect the main water supply to the faucet body.
- 10. If your faucet features a hand shower and diverter, follow steps 6-8 listed above and attach the water feed tubes accordingly.
- 11. After all the connections have been made, turn on the water supply, check to make sure that all connections are tight (no water should be leaking) and that the hot and cold supplies are working correctly. Turn the faucet on and allow the water to flow through the spout for approximately 60 seconds. If you have a hand shower, divert the water to the hose and allow the water to flow through the hose for an additional 60 seconds.

CARE INSTRUCTIONS

To preserve the finish of your product, apply non-abrasive wax. Any cleaners should be rinsed off immediately. Do not use abrasive cleaners on the product.