



# SOLID BRASS EXTRA LONG ROOK DOORSTOP INSTALLATION

## BEFORE INSTALLING

Before you begin, read the installation instructions below.

Observe all local building and safety codes. .

---

## INSTRUCTIONS

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1.866.855.2284. If you need assistance or have questions while installing, contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing hardware. Signature Hardware accepts no liability for any damage to the home, the product, or for personal injury during installation.

---


## TOOLS AND MATERIALS:



Screwdriver



Hammer



Drill



Pencil

## INSTALLATION

1. Remove the rubber pad from the end of the doorstop.

**Tip:** Use a flat tool, such as a putty knife, to pry the pad loose.

2. Place the doorstop in its desired location. Note the small pin on the base of the doorstop, which is used to prevent the doorstop from loosening itself after installation. Use a hammer to strike the doorstop into the baseboard until the pin sets.

3. While holding the doorstop in place, insert a pencil into the end of the doorstop and mark the location of the mounting hole on the baseboard. Once marked, set the doorstop aside.

4. Drill a small pilot hole into the baseboard at the marked installation location.

5. Insert the supplied mounting screw into the doorstop, so that it passes through the mounting hole on the base.

6. Place the doorstop back into position at its installation location. Guide the mounting screw into the pilot hole drilled in step 4, then use a flathead screwdriver to tighten. Ensure that the pin fits back into its impression that was made in step 2.

7. Once the doorstop is installed, reattach the rubber pad to the end of the doorstop. Use a hammer if necessary.