



# SHOWER BASKET

## BEFORE INSTALLING

Read entire Shower Basket Installation Instructions. Observe all local building and safety codes.

## INSTRUCTIONS

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1-855-715-1800. If you need assistance or have questions while installing your shower basket, contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures. Signature Hardware accepts no liability for any damage to the floor or walls, or for personal injury during installation.

## TOOLS AND MATERIALS:



Pencil



Screwdriver



Level



Drill



Masking Tape

## INSTALLATION

1. Determine the installation location and mark the location of the pilot holes using the mounting holes in the shower basket. Use a level to verify that your basket is properly aligned.

**Tip:** Place a piece of masking tape in the installation location when marking the location of the mounting holes. This will enable you to clearly see the outlines you are creating and help to keep your drill from damaging the mounting surface.

2. Drill the pilot holes with the appropriate drill bit for the wall surface or material.

3. Insert the screws (**B**) into the screw jackets (**C**), and place in the mounting bracket.

4. Attach the shower basket to the wall by inserting the screws (**B**) into the pilot holes and securing with your drill or screwdriver.

5. Once your shower basket is installed, screw the button covers (**A**) onto the screw jackets (**C**).

