

RIDGEWAY PULL-DOWN TOUCHLESS KITCHEN FAUCET WITH DECK PLATE

SKU: 951733-S

Code: SH482241, SH482397, SH482398, SH482399



FEATURES

Installation Type: Single-Hole
Features: Pull-Down
Design: Modern
Length: 10-1/4"
Width: 11-1/4"
Height: 16-7/8"
Base Plate Length: 10-1/4"
Faucet Centers: Single-Hole
Drain Included: No
Faucet Material: Brass
Handle Type: Lever
Handle Length: 4"
Base Plate Width: 2-1/4"
IPS: 1/2"
Flow Rate: 1.75 gpm @60 psi
Kitchen Faucet Holes: 1
Hand Sprayer Material: Plastic
Max. Countertop Thickness: 2 3/4"
Height To Spout: 8"
Spout Reach: 9-1/8"
Swivel Spout: Yes
Handle Height: 1-5/8"
Ceramic Disc Cartridges: Yes
Hot and Cold Indicators: No
Weight: 6.6

REVISED 3/30/2023

RIDGEWAY PULL-DOWN TOUCHLESS KITCHEN FAUCET WITH DECK PLATE

SKU: 951733-S

Code: SH482241, SH482397, SH482398, SH482399




ADDITIONAL FEATURES

- The sensor is activated when motion is detected 2-3/8" in front of the spout.
- A manual override option exists for those who wish to turn off sensor technologies.
- Four AA batteries are included for your convenience.
- Sprayer Button Functions: Stream and spray.
- Spray activation type: Button
- Included deck plate can be used to cover unused faucet holes.

REVISED 3/30/2023

RIDGEWAY PULL-DOWN TOUCHLESS KITCHEN FAUCET WITH DECK PLATE

SKU: 951733-S
SHXCRD100E, OBPF1F80037



All dimensions and specifications are nominal and may vary. Use actual products for accuracy in critical situations.