



FREESTANDING TUB FAUCET

INSTALLATION INSTRUCTIONS

Before you begin, read the installation instructions below. Observe all local plumbing and building codes.

Caution: Do not grab or hold on to faucet or risers for support.

Unpack and inspect faucet and parts for damage. If any damage is found, contact Customer Service at 1-866-855-2284 and return faucet to container. If you need assistance while installing your new faucet, call our Customer Service number.

Your application and circumstances may call for variations to the installation instructions. We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures and plumbing. Signature Hardware accepts no liability for any damage to the floor, walls, plumbing, or personal injury during installation.

For the following installation instructions for your new faucet it is assumed that the water supply lines are in place underneath the floor and are directly accessible for installation

Riser location will vary depending on the width of the faucet centers and tub rim. We recommend that the spout of your faucet extend out approximately 3"-5" over the interior of the tub.

TOOLS AND MATERIALS:

Adjustable Wrench
Level
Damp Cloth

Tape Measure
Silicone Sealant


Plumber's Tape
Thread Sealant


INSTALLATION

1. Slide the slip nuts (**B**) up the upper riser pipes (**C**).
2. Thread the bell flanges (**D**), lock nuts (**E**), and rubber washers (**F**) onto the riser pipes (**C**). Insert the pipes into the installation holes in the finished floor.

Note: Apply the supplied thread sealant to all threaded connections. Wipe away any excess sealant with a damp cloth.

3. Thread the metal washers (**G**), and locknuts (**H**) onto the riser pipes via the under the floor access space. Connect the riser pipes to the main water supply with the rubber washers (**I**) and NPT adapters (**J**).
4. Place the remaining rubber washers (**A**) in the slip nuts at the top of the supply pipes and install the tub faucet according to the faucet installation instructions.





5. Attach the faucet to the upper riser pipes and tighten the slips nuts to secure. Allow sealant to cure for 24 hours before use.
6. Place a washer inside the base of the hand-held shower cradle and attach the cradle to the faucet body.
7. If included, attach the hand shower hose and rubber washers to the shower cradle outlet and hand-held shower. Place the hand-held shower in the cradle.
8. Turn on the main water supply.
9. To remove debris, turn the faucet on and allow the water to run through the spout for approximately 60 seconds. Divert the water to the hand shower and allow the water to flow through the hose for approximately 60 seconds. Check to make sure that all connections are tight (no water should be leaking).

PARTS LIST:

- A. (2) Rubber Washer
- B. (2) Slip Nut
- C. (2) Riser Pipe
- D. (2) Bell Flange
- E. (2) Lock Nut
- F. (2) Rubber Washer
- G. (2) Metal Washer
- H. (2) Lock Nut
- I. (2) Rubber Washer
- J. (2) NPT Adapter

