

TRITON

WALL-MOUNT BATHROOM FAUCET

SKU: 453245

BEFORE YOU BEGIN

We recommend consulting a professional if you are unfamiliar with installing plumbing fixtures. Signature Hardware accepts no liability for any damage to the faucet, plumbing, wall, or for personal injury during installation.

Observe all local plumbing and building codes.

Unpack and inspect the product for shipping damage. If any damage is found, contact our Customer Relations team at 1-855-715-1800.

GETTING STARTED

- Ensure that you have gathered all the required materials that are needed for the installation.
- For these instructions, it is assumed that the old faucet has been completely removed and any necessary repairs or modifications to the water supply have been completed.

TOOLS AND MATERIALS:



Drill



Level



Wood Screws



Silicone Sealant
(100% Neutral Cure)

For Warranty information, please visit: signaturehardware.com/services/warranty

REVISED 03/27/2020
CODES: 508688

TRITON

WALL-MOUNT BATHROOM FAUCET

SKU: 453245

INSTALLATION

1. Install the rough-in valve body behind the finished wall. Attach the valve body to wood blocking between two wall studs with wood screws. Be sure that the rough-in valve is completely level, and connect to the main water supply.
2. When the wall around the rough-in valve is finished, install your faucet trim.
3. If your faucet spout is not assembled, assemble by connecting the threaded outlet to the faucet body. If your spout is already assembled move on to the next step.
4. If your faucet features a decorative face plate, secure the face plate to the wall with silicone sealant before installing your handle and spout trim pieces. Make sure that the face plate is properly aligned over the rough-in valve and perfectly straight. If your faucet does not feature a face plate move on to the next step.
5. If the decorative spout escutcheon is not attached, place the escutcheon on the body of the spout and install the spout over the spout shank. Screw the spout into place and press the escutcheon firmly against the finished wall.

6. Tighten any set screws in the spout with the provided allen wrench.

7. Install the handle(s) and any necessary hardware and tighten the set screws with with your allen wrench. If O-rings or sealing gaskets are included, place between the handle body and wall to create a water tight seal.

8. When your faucet installation is complete, turn on the water supply. Check to make sure that all connections are tight (no water should be leaking) and that the hot and cold supplies are working correctly. Turn the water on and allow the water to flow through the spout for approximately 60 seconds. Allow sealant to cure for 24 hours before use.

CARE INSTRUCTIONS

To preserve the finish of your product, apply non-abrasive wax. Any cleaners should be rinsed off immediately. Do not use abrasive cleaners on the product.