

OUTDOOR STAINLESS STEEL SHOWER PANEL WITH BAMBOO TRAY

SKU: 417701

BEFORE YOU BEGIN

Before installing, read entire outdoor shower installation Instructions. Observe all local building and safety codes.

For the following installation instructions it is assumed that the water supply has been installed in the desired location and is accessible for shower installation.

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1.866.855.2284. If you need assistance or have questions while installing your shower panel, contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures. Signature Hardware accepts no liability for any damage to the seat or wall, or for personal injury during installation.

Note: Make sure to winterize your outdoor shower before cold weather arrives to prevent burst pipes and protect the shower's hardware.


GETTING STARTED

- Ensure that you have gathered all the required materials that are needed for the installation.
- For these instructions, it is assumed that the old faucet has been completely removed and any necessary repairs or modifications to the water supply have been completed.

TOOLS AND MATERIALS:



Adjustable
Wrench



Air Compressor

INSTALLATION

1. Lay the shower panel down flat so that all parts can be easily viewed and accessed during assembly. Line up the mounting holes on the shower column and tray.
2. Place the reinforcement plate on the bottom of the tray in line with the mounting holes. Insert the assembly bolts through the plate, tray and mounting holes in the shower column.
3. Thread the washers and nuts onto the bolts, and tighten with the appropriate wrench.
4. Set the shower panel in the desired installation location. If necessary, adjust the shower by tightening the levelers on the bottom of the tray.
5. Insert the shower arm into the fitting in the panel and twist to tighten. Finish tightening with an adjustable wrench. Wrap a dry cloth around the shower arm to protect the finish while tightening.
6. Thread the shower head onto the arm and hand-tighten.
7. Attach the hand shower hose to the outlet on the side of the shower panel. Do this gradually, alternating from one nut to the other until both are tight
8. Connect the water inlet hose on the back of the panel to the water supply.
9. Turn on the water supply to make sure there are no leaks in the water feed tube(s).


If leakage does occur, use your adjustable wrench to tighten the connections as necessary. If problems persist, contact Customer Service at 1-866-855-2284. If no leaks are detected, turn on the shower panel and check to make sure that all connections are. Divert the water to the each output and allow the water to flow for approximately 60 seconds.

CARE AND MAINTENANCE

To maintain the natural wood finish, install and store the shower panel in a dry, well ventilated space. Do not clean the shower or shower tray with any acidic soaps or detergents. After use, rinse with clean water and wipe dry to remove any dirt or soap residue as this may damage the bamboo over time. To protect the finish and extend the lifetime of your outdoor shower, remove hard-soled shoes prior to stepping onto the shower tray.


WINTERIZING

1. Locate the shutoff valves for the outdoor shower unit. Turn off the shower's water supply.
2. Disconnect the supply lines from the back of the shower unit using the adjustable wrench.
3. Remove the shower head if possible.
4. Open the valve to the HOT position.
5. Insert the air blower from the air compressor into the HOT inlet hose. Blow compressed air into the hose until no more water comes out of the shower head.
NOTE: The hoses may differ from your installation. Identify which is the hot and which is the cold supply.



6. Open the valve to the COLD position.

7. Insert the air blower from the air compressor into the COLD inlet hose. Blow compressed air into the hose until no more water comes out of the shower head.
NOTE: The hoses may differ from your installation. Identify which is the hot and which is the cold supply.



8. As a final check, place the temperature selector in the middle range.

9. Insert the air blower tool from the air compressor into the COLD inlet hose as shown in Step 5. Blow compressed air into the hose until no more water comes out of the shower head.
Repeat for the HOT inlet hose.

When no more water comes out of the shower head, winterizing is complete.

10. Replace shower head if previously removed.