

OUTDOOR SHOWER

STAINLESS STEEL WITH PULL CHAIN INSTALLATION INSTRUCTIONS

SKU: 401595

BEFORE YOU BEGIN

Before installing, read entire outdoor shower installation Instructions. Observe all local building and safety codes.

For the following installation instructions it is assumed that the water supply has been installed in the desired location and is accessible for shower installation.

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1.855.715.1800. If you need assistance or have questions while installing your shower panel, contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures. Signature Hardware accepts no liability for any damage to the seat or wall, or for personal injury during installation.

Note: Make sure to winterize your outdoor shower before cold weather arrives to prevent burst pipes and protect the shower's hardware.

GETTING STARTED

- Ensure that you have gathered all the required materials that are needed for the installation.
- For these instructions, it is assumed that the old faucet has been completely removed and any necessary repairs or modifications to the water supply have been completed.

TOOLS AND MATERIALS:



Damp Cloth




Drill



Pencil



Silicone Sealant
(100% Neutral
Cure)



Air Compressor

REVISED 07/10/2019

OUTDOOR SHOWER

STAINLESS STEEL WITH PULL CHAIN INSTALLATION INSTRUCTIONS

SKU: 401595

INSTALLATION

1. Apply plumbers tape (included) to the threaded ends of the 6" pipe and attach the pipe directly to the water supply line.
2. Slide the decorative escutcheon over the pipe.
3. Thread the pull chain valve onto the 6" pipe. Hand tighten and adjust as necessary for proper alignment.
4. Slide the support arm onto the shower arm.
5. Wrap plumbers tape around the threaded ends of the shower arm. Attach the shower arm to the pull chain valve.
6. Hold the support arm in place and mark the location of the mounting holes in the wall flange on the installation surface.
7. Drill pilot holes in the locations marked in the previous step and install anchors (included). Drive mounting screws through the flange, into the anchors, to attach the support arm to the installation surface.
8. Tighten the set screw on the support arm with the provided Allen wrench.
9. Attach the shower head to the shower arm.
10. Turn on the water supply to check for leaks. If no leaks are detected, apply silicone sealant to the back of the decorative escutcheon and press into place against the installation surface. Wipe away any excess sealant with a damp cloth. Allow the silicone sealant to dry for 24 hours.


OUTDOOR SHOWER

STAINLESS STEEL WITH PULL CHAIN INSTALLATION INSTRUCTIONS


SKU: 401595

WINTERIZING

1. Locate the shutoff valves for the outdoor shower unit. Turn off the shower's water supply.
2. Disconnect the supply lines from the back of the shower unit using the adjustable wrench.
3. Remove the shower head if possible.
4. Open the valve to the HOT position.
5. Insert the air blower from the air compressor into the HOT inlet hose. Blow compressed air into the hose until no more water comes out of the shower head.
NOTE: The hoses may differ from your installation. Identify which is the hot and which is the cold supply.



6. Open the valve to the COLD position.
7. Insert the air blower from the air compressor into the COLD inlet hose. Blow compressed air into the hose until no more water comes out of the shower head.
NOTE: The hoses may differ from your installation. Identify which is the hot and which is the cold supply.



8. As a final check, place the temperature selector in the middle range.
 9. Insert the air blower tool from the air compressor into the COLD inlet hose as shown in Step 5. Blow compressed air into the hose until no more water comes out of the shower head.
Repeat for the HOT inlet hose.
- When no more water comes out of the shower head, winterizing is complete.
10. Replace shower head if previously removed.