



ULTRA WIDESPREAD BATHROOM FAUCET

BEFORE YOU BEGIN

We recommend consulting a professional if you are unfamiliar with installing plumbing fixtures. Signature Hardware accepts no liability for any damage to the faucet, plumbing, sink, counter top, or for personal injury during installation.

Observe all local plumbing and building codes.

Unpack and inspect the faucet for shipping damage. If any damage is found, contact our Customer Relations team at 1-866-855-2284.

GETTING STARTED

- Ensure that you have gathered all the required materials that are needed for the installation.
- For these instructions, it is assumed that the old faucet has been completely removed and any necessary repairs or modifications to the water supply have been completed.

TOOLS AND MATERIALS:



Plumbers
Tape



Thread
Sealant



Hex Wrench



Adjustable
Wrench



Small
Bucket



Basin
Wrench




ULTRA WIDESPREAD BATHROOM FAUCET


INSTALLATION

1. Ensure that the water supply below your sink is completely shut off by turning the shutoff valves all the way to the right.


Tip: Place a small bucket below your workspace to catch any water that may drip during the installation.




2. Remove the T-connector, lock nut, metal washer, and rubber washer from the spout's threaded mounting post.



3. Set the spout into the center mounting hole. From beneath the countertop, slide the rubber gasket followed by the metal washer back onto the threaded mounting post. Hand tighten the lock nut, then finish tightening using an adjustable wrench.




4. Thread the T-connector onto the end of the spout's threaded mounting post. Apply thread sealant or plumber's tape to the threads before tightening. Hand tighten firmly.






ULTRA WIDESPREAD BATHROOM FAUCET


5. The faucet's valve stems are labeled by their colored lock nuts— red for hot and blue for cold. Remove the cold stem from its handle by unthreading the stem from the handle base. Remove the rubber washer, brass spacer, and friction washer along with the stem.



6. Set the removed handle into the right-side faucet hole. From beneath the counter top, insert the valve stem into the right-side faucet hole. Hand-tighten the stem into the handle base firmly. Hand tighten the blue lock nut until the stem is secure, then finish tightening using a basin wrench.




7. Repeat steps 5 & 6 to install the 'hot' valve stem into the left-side faucet hole.



8. Use the provided braided water lines to connect each stem to the spout's T-connector, as shown. Apply thread sealant or plumber's tape to each threaded connection. Use an adjustable wrench to tighten, but be careful not to overtighten.


Tip: Hand tighten each water line connection, then finish tightening by giving the nut a ¼ turn with an adjustable wrench.






ULTRA WIDESPREAD BATHROOM FAUCET

9. Attach the main water lines to the proper inlet on the bottom of each valve stem. Apply thread sealant or plumber's tape to each threaded connection. Ensure that you are connecting the hot and cold lines appropriately. Use an adjustable wrench to tighten, but be careful not to overtighten.




10. It is very likely that the hot and cold handles will need to be adjusted to the proper position. To remove the handles, loosen the set screw located on the handle base. Remove the handle, position properly, then reattach.



11. Once installation is complete, turn the main water supply back on from below your sink. Check for any leaks underneath.



12. Once drain installation is complete, turn the faucet on for approximately 60 seconds to check for any leaks. Test both hot and cold water to ensure they are running properly.







BATHROOM SINK DRAIN INSTALLATION

DRAIN INSTALLATION


1. Dissassemble the drain assembly and lay the parts aside, in the same order they were removed. See the illustration below as a reference if needed.



2. Apply plumber's tape to the threading on the tailpiece, then reattach the tail piece to the pop-up drain flange.




3. Slide the flat rubber gasket up the tailpiece until it meets the lip of the pop-up drain flange.






BATHROOM SINK DRAIN INSTALLATION

4. Insert the drain flange and tailpiece through the top of your sink's drain hole.



5. From under your counter, slide the tapered rubber gasket followed by the plastic friction washer onto the tailpiece until they meet your sink or countertop. Be sure that the tapered side of the rubber washer is facing up.



6. Thread the lock nut onto the drain flange. Hand tighten until secure, then finish tightening with a basin wrench once the drain is properly aligned.

Important: Be careful not to overtighten, which could crack a porcelain sink or stone countertop.

